

**INDUSTRIAL ASSETS MACHINERY
IS PLEASED TO OFFER FOR YOUR CONSIDERATION:**

REFERENCE #: 4717

Komatsu OBS Press

MODEL: OBS 200 HVS-3, S/N: D0048 Year: 1997

- Tonnage...200
- Ram Stroke...5.51"
- Shut Height...18.90"
- Ram Adjustment...4.72"
- Bed Size...57" x 35"
- Ram Size...33" x 25"
- Strokes Per Minute...40-80
- Opening Thru Back...37"
- Dimensions...94" x 80" x 181"
- Weight...40,000 LBS

EQUIPPED WITH

- Air Clutch & Brake
- Hydraulic Overload Protection
- T-Slotted Bolster & Ram
- Power Ram Adjustment With Indicator
- Auto Lube System
- Remote Dual Palm Control Stand
- Barrier Guards
- Isolator Pads
- Horsepower:20

PRICE: \$89,500

LOCATION: Huntington Park, CA

LEASE PAYMENT OPTION

*\$2,414.00 /month for 36 months

To apply for financing please contact Tiffany Guimond at 818-508-7034 or email tguimond@biditup.com.
To submit a credit application online, click [here](#)

*Payments are based (OAC), 36 months term, 25% down payment, shorter or longer terms available. This advertisement in no way constitutes an offer to buy or sell equipment from Industrial Assets Machinery or BIDITUP or for Charcole Capital to provide financing or leasing. Payments exclude destination, rigging and transportation charges, any applicable taxes, and any applicable fees. Any calculation of any price, tax, lease or finance terms is for your reference only, is an estimate, and is subject to change without notice.





MADE IN MEXICO
 MANUFACTURED BY DINA
 THROUGH TECHNICAL
 ASSISTANCE KOMATSU

MAIN SPECIFICATIONS

MODEL	JBS 200 H-VS-3
MACHINE NO	00048
DATE MANUFACTURED	9 1996
MAXIMUM CAPACITY	200 (22000) metric ton (short ton)
NUMBER OF SLIDE STROKES	50 - 80 rpm
SLIDE STROKE	140 (551) mm (inch)
DIE HEIGHT (BETWEEN BOLSTER AND SLIDE) STROKE DOWN ADJUSTMENT UP	480 (18.90) mm (inch)
SLIDE ADJUSTMENT	120 (4.72) mm (inch)
SLIDE DIMENSIONS (LR x FB)	850 X 650 mm (33.46 X 25.59 inch)
BOLSTER DIMENSIONS (LR x FB x THICKNESS)	1450 X 890 X 190 mm (57.09 X 35.04 X 7.48 inch)

Dina Komatsu Nacional S. A. De C. V.

WARNING

TO PREVENT SERIOUS BODY INJURY

NEVER PLACE ANY PART OF YOUR BODY UNDER THE SLIDE OR WITHIN THE DIE AREA.

NEVER INSTALL DIES OR SERVICE THIS MACHINE WITH THE FLYWHEEL IN MOTION. MOTOR ON OR THE SLIDE IN AN UNLOCKED POSITION.

NEVER OPERATE SERVICE OR ADJUST THIS MACHINE OR INSTALL DIES WITHOUT PROPER INSTRUCTION AND WITHOUT STRICTLY FOLLOWING THE INSTRUCTIONS IN THE...

